


User's Guide

Place the pastry on top

Raise the tray and use **low setting**

no more soggy pizzas and pies



WARNING Over cooking in microwave ovens begins with popping sounds then splattering. The food finish hard as a rock, chewy, tasteless or unpalatable.

Don't blame the microwave or tray, it's your fault, just lower the heating setting and try again

PRODUCTS	Microwave Oven					
	INVERTER LARGE 1,100 watts			STANDARD LARGE 1,000 watts		
	Power	Frozen	Thawed	Power	Frozen	Thawed
Pizza (single)	3	3 min	1 min	Low	2 min	1 min
Pizza (family)	3	4 min	2 min	Low	4 min	2.5 min
Battered Fish (single)	2	2 min	1.5 min	Low	1 min	30 sec
Tempura (single)	2	2 min	1.5 min	Low	1 min	30 sec
Frozen Fish (4)	2	2 min	1.5 min	Low	1 min	30 sec
Fish Finger (4)	2	2 min	1.5 min	Low	1 min	30 sec
Tomkatsu (single)	2	2.5 min	1 min	Low	1 min	30 sec
Schnitzel (single)	2	2.5 min	1 min	Low	1 min	30 sec
Meat Pie (single)	4	2.5 min	1 min	Low	3 min	2 min
Sausage Roll (single)	4	2.5 min	1 min	Low	2 min	1.5 min
Bun (single)	2	15 sec	10 sec	Low	15 sec	10 sec
Croissant / Biscuit (single)	2	15 sec	10 sec	Low	15 sec	10 sec

FREEZERS AND MICROWAVE OVENS EFFICIENCY VARIES, PLEASE ADJUST SETTING ACCORDINGLY


- The tray should be washed in dishwashers top rack, or by hand and never with abrasive scrubber.
- MICROFAN intellectual property is protected by current international patents.

WARNING

Microwaves can easily overheat sugars, oil and fat to harmful temperatures that may burn deeply on contact

DISCLAIMER

MICROFAN is not liable for any damage caused to others or property due to use or misuse of the product



Warning Hot Food



No Flame or Heat



Microwave Safe



Dishwasher Safe



Freezer Safe



Recyclable Material